

ILLUSTRATED PARTS LIST


MFG ID NO. 96042000600

CUSTOMER CATALOG NO. PBGT22H54

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)


SCHEMATIC

02929-194276_Regulated-TEX



TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)


DECALS



KEY NO.	PART NO.	DESCRIPTION
1	402104	Decal, Operator's
2	402355	Decal, Hood RH
3	402527	Decal, Chassis
4	402226	Decal, Replacement
5	172743	Decal, Strg Whl
6	189489	Decal, Engine HP
8	198785	Decal, Mower Sch.
9	145005	Decal, Battery Dnge/Poi
10	402357	Decal, Hood LH

KEY NO.	PART NO.	DESCRIPTION
11	178502	Decal, Mower Caution
12	170563	Decal, Mower Warning Keep Hand Away
13	172740	Decal, Fender
14	401131	Decal, Panel SD
--	166960	Decal, Bypass
--	193279X428	Pad, Footrest, LH
--	193101X428	Pad, Footrest, RH
--	402495	Manual, Operator's (Eng & French)
--	402496	Manual, Parts


WHEELS AND TIRES



KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap, Valve, Tire
2	65139	Stem, Valve
3	106228X421	Rim Assembly, Front
4	59904	Tube, Front (Service Item Only)
5	106230X	Tire, Front
6	278H	Fitting, Grease (Front Wheel Only)
7	9040H	Bearing, Flange (Front Wheel Only)
8	104757X421	Cap, Axle (Front Wheel Only)
9	184708	Tire, Rear
10	7152J	Tube, Rear (Service Item Only)
11	400404X421	Rim Assembly, Rear
--	144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)
ELECTRICAL



TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)


ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION
1	144927	Battery
2	74760412	Bolt Hex Head 1/4-20 x 3/4
8	186491	Box Battery
16	176138	Switch Interlock Push-In
21	175688	Harness Socket Light W/4152J
22	4152J	Bulb Light
24	400253	Cable Battery
25	198893	Cable Start Red
26	175158	Fuse
27	73510400	Nut Keps Hex 1/4-20 unc
28	145491	Cable, Ground
29	401545	Switch, Seat
30	193350	Switch, Ignition
33	140401	Key, Ignition
34	110712X	Switch Light / Reset
40	194276	Harness Ignition
41	17720408	Screw Thd Cut 1/4-20 x 1/2
42	131563	Cover, Terminal
43	192507	Solenoid
46	198138	Gauge Hourmeter
50	174653	Switch, PTO
55	17490512	Screw Thdrol 5/16-18 x 3/4 TYTT
59	400303	Outlet 12-Volt
71	400260	Harness Ign. Dash
79	175242	Bulbholder Asm. Incan Descent
90	180449	Cover Terminal Battery
91	190270	Strap Battery Mount Front
99	17670412	Screw Hexwsh Thdrol 1/4-20 x 3/4
100	19091416	Washer 9/32 x 7/8 x 16 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

CHASSIS



chassis-tex_15-vgt-hydro


TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

CHASSIS

KEY NO.	PART NO.	DESCRIPTION
2	401140	Drawbar
5	195102X428	Dash
14	175260X428	Hood
17	17060612	Screw 3/8-16 x .75
18	175289X428	Grille
37	193094X428	Fender
58	194314	Bracket Fender
68	17490508	Screw Thdrol 5/16-18 x 1/2
99	198253	Rod Bypass Asm.
122	192512	Screw WSHD Hex 10-32 x 5/8
130	191611	Screw 10 x 3/4 Single Lead-Hex
148	164655	Bumper
150	175352	Duct Heat Hood
152	194329	Shield Browning/Debris
157	161840	Lens Bar
159	17000612	Screw Hexwsh Thdrol 3/8-16 x 3/4
161	193097X428	Console Fuel Window
162	142432	Screw Hex Wsh Hi-Lo 1/4 x 1/2
165	194330	Bracket Support Tank
175	193236	Crossmember
176	400776	Screw #10-24 x 5/8 Rnd Qudrx
177	195227	Bushing Steering
178	195651	Cargo Asm. Net
180	194260	Chassis
181	193102X428	Bushing Mtg. Fender Crgo.
182	192551	Dash Lower
183	74780520	Bolt Fin Hex 5/16-18UNC x 1-1/4
184	195780	Spacer Fender
188	194316	Bracket Pickoff Hood
189	17000512	Screw 5/16-18 x 3/4
194	73900500	Nut Lock Hex Flange 5/16-18
196	193098X428	Console Asm. Deck Lift
198	197300X505	Indicator Deck Lift
199	196377	Plate Deck Lift
205	169847X428	Skirt Hood RH
206	169848X428	Skirt Hood LH
219	195161	Stud Fastener
222	137729	Screw thd Roll 1/4-20 x 5/8

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

DRIVE



TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

DRIVE


KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle, Hydro 318-0610 (Order Parts from Transaxle Manufacturer)
2	186211	Key 1.87 x 2.500
7	199844	Hub Asm. Wheel
9	140080	Bolt Hub Wheel
15	19131316	Washer 13/32 x 13/16 x 16 Ga.
17	197296	Spring, Brake
26	199679	Spring Return Cruise
29	199467	Rod, Brake
33	12000001	Ring E #5133-75
35	197275	Rod, Brake, Park
37	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
42	123533X	Cover, Foot Pedal
49	72110614	Bolt
50	194327	Pulley Idler Flat
51	73900600	Lock Nut 3/8-16
52	194326	Idler V-Groove 910" Offset
56	140218	V-Belt, Drive
64	197865	Shaft Asm. Pedal Brake Control
74	142432	Screw 1/4 x 1/2
80	400507	Bracket Strp. Trq.
92	74760520	Bolt Fin Hex 5/16-18 unc x 1.25
116	73900500	Nut Lock Hex Flange 5/16-18
125	17000512	Screw 5/16-18 x 3/4
153	4497H	Retainer Spring 1"
159	76020412	Pin Cotter 1/8 x 3/4
160	169484	Retainer Clip
161	195403	Spring, Return, Clutch
162	195785	Spacer Trans.
163	199000	Rod Control Cruise
166	197290	Nut Push .625

KEY NO.	PART NO.	DESCRIPTION
167	196211	Latch Brake Parking
169	74490560	Bolt Hex Flngd. 5/16-18 x 3.75
170	194322	Keeper Belt Centerspan
171	72110616	Bolt
183	400424	Spacer Split 800 x 350.
184	195361X428	Handle Parking Brake
185	72110620	Bolt
186	194321	Spacer Retainer
187	19133210	Washer
188	194323	Link Clutch Ground Drive
189	194317	Bellcrank Ground Drive
190	194318	Keeper Bellcrank Ground Drive
196	17000616	Screw 3/8-16 x 1
197	199769	Bracket Clutch Anti-Rotation
203	19111116	Washer 11/32 x 11/16 x 16 Ga.
205	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
206	197867	Bracket Mount Latch Cruise
207	197868	Latch Control Cruise
208	197869	Gear Sector Control Cruise
209	199466	Rod Control Cruise
210	197860	Rocker Asm. Pedal Control
211	120183X	Bearing Nylon Blk .629
213	195352X428	Knob Control Cruise
214	197302X428	Pedal Forward
215	197301X428	Pedal Reverse
221	403187	Retainer Spring Clip Handle
222	19212010	Washer 21/32 x 1-1/4 x 10 Ga.
224	193099X428	Console Toolbox

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

STEERING ASSEMBLY



TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)


STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	186093X428	Wheel, Steering
2	195968	Axle Asm., Front
4	197937	Spindle Asm., LH
5	197936	Spindle Asm., RH
6	6266H	Bearing, Race Thrust Harden
7	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
8	12000029	Ring, Klip #T5304-75
9	121232X	Cap, Spindle
13	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
14	STD551137	Washer, Lock Hvy Hlcl Spr 3/8
15	73540600	Nut, Crown Lock 3/8-24 unf
16	194746	Shaft Steering
19	194729	Plate Steering
20	195626X428	Boot, Steering
21	186737	Adapter, Wheel Steering
22	194845	Bushing, Strg. Blk
26	186095X428	Insert, Wheel Steering
28	17000612	Screw 3/8-16 x 3/4
35	194732	Gear, Sector Plate
45	19183812	Washer 9/16 x 2-3/8 x 12 Ga.
50	73900600	Nut Lock Flg. 3/8-16 unc
51	73940800	Nut Hex Jam Toplock 1/2-20 unf
53	188967	Washer Hardened .793 x 1.637 x .060
54	74760636	Bolt Hex Hs 3/8-16 unc x 2-1/4
55	197636	Spacer Brace Axle
57	197246	Bracket Upstop
58	194747	Bolt Shoulder Sector Pivot CFM
59	194748	Washer Thrust Sector Steering
60	73971000	Nut Flange Lock 5/8-11
61	194740	Draglink LH
62	194741	Draglink, RH
63	17000512	Screw 5/16-18 x 3/4
64	199849	Retainer Clip Spring Steering
65	194734	Brace Axle Front
66	71020748	Bolt Hex Fghd 7/16-14 x 3 Serr
67	194737	Bushing PM Front Axle
68	73900700	Nut Lock Flange 7/16-14 Gr. 5
69	199162	Washer 1.5 x .505 x .118
70	196197	Bracket Deck Susp. Front

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

SEAT ASSEMBLY



seat-tex_7-vgt


KEY NO.	PART NO.	DESCRIPTION
1	197530	Seat
2	180166	Bracket Pivot Fender
3	140675	Strap, Asm Fender
5	145006	Clip, Push In, Hinged
6	STD541437	Nut, Lock W/Ins. 3/8-16 unc
7	124181X	Spring, Seat Cprsn
8	171877	Bolt 5/16-18 unc x 3/4 w/Sems
10	196977	Pan, Seat

KEY NO.	PART NO.	DESCRIPTION
21	171852	Bolt, Shoulder 5/16-18
37	STD541431	Nut, Lock 5/16-18 unc
40	197661	Handle Slide Seat
41	198200	Spring Latch Seat
43	74760612	Bolt Fin Hex 3/8-16 unc x 3/4
44	19133812	Washer 13/32 x 2-3/8 x 12 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

ENGINE



engine-tex_11-vgt


SPARK ARRESTER KIT

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Engine B&S Model No. 441777	41	126197X	Washer 1-1/2 OD x 15/32 ID x .250
2	149723	Muffler	42	STD551143	Washer Lock 7/16
9	194319	Keeper Asm. Belt Engine	45	73510400	Nut Keps Hex 1/4-20 unc
11	179335	Clutch Electric	62	146629	Shield Heat Muffler
12	402463	Pulley Engine	69	165391	Gasket
15	193499	Tank Fuel 4.0	70	159955	Tube Exhaust LH
18	195951	Cap Asm	71	160589	Tube Exhaust RH
20	175437X428	Control Throttle	79	183906	Screw Socket Head
21	191611	Screw 10 x 3/4 Single Lead-Hex	81	148456	Tube Drain Oil Easy
22	187768X428	Control Choke	82	181654	Plug Drain Oil
28	401135	Fuel Line	84	17060624	Screw 3/8-16 x 1-1/2
29	137180	Spark Arrester Kit	85	179953	Bolt Hex 7/16-20 x 3.75 Gr. 5
31	145006	Clip Push-In Hinged	87	198239	Bolt 5/16-18 unc x 1 w/Sems
37	123487X	Clamp Hose	90	17000616	Screw 3/8-16 x 1

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

MOWER DECK



TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

MOWER DECK


KEY NO.	PART NO.	DESCRIPTION
1	195632X421	Deck Weldment Mower
6	196066	Cover Mandrel LH
7	197181	Cover Mandrel RH
8	174365	Bolt 7/16 Asm. Blade
- -	187255	Blade Mulching
11	187256	Blade Bagging
12	400337	Rod Anti-Sway
13	187291	Shaft Asm. w/Lower Bearing
14	187281	Housing, Mandrel
15	110485X	Bearing, Ball, Mandrel
16	19131312	Washer 13/32 x 13/16 x 12 Ga.
17	72110505	Bolt Carr. 5/16-18 x 5/8
19	194208	Pin Cotter 5/16 Bow Tie Lock
21	73680500	Nut, Crownlock 5/16-18 unc
24	105304X	Cap Sleeve
25	178102	Spring, Torsion
26	110452X	Nut, Push
27	187257X428	Deflector Shield
29	131491	Rod, Hinge
30	173984	Screw, Thdroll Washer Head
31	187690	Washer, Spacer Mower Vented
32	173436	Pulley, Mandrel
33	400234	Nut, Flg. Top Lock
34	73680600	Nut Crownlock 3/8-16UNC
39	196104	Pulley, Idler, Stationary
43	196065	Arm, Idler
46	137729	Screw, Thdroll. 1/4-20 x 5/8
47	196103	V-Belt, Mower
49	73900600	Nut, Lock Flg. 3/8-16 unc

KEY NO.	PART NO.	DESCRIPTION
50	72110606	Bolt RDHD SQNK 3/8-16UNC x 2
52	196106	Pulley Idler Clutching
58	187342	Baffle Right
59	187344	Baffle Left
60	187607	Baffle Center
97	178515	Washer Hardened
98	196105	Spring Drive
113	72110508	Bolt Rdhd Sqnk 5/16-18 x 3/4
114	187556	Rod Tension Relief
116	193406	Bolt, Shoulder
117	174873	Gauge Wheel
120	19132012	Washer 13/32 x 1-1/4 x 12Ga.
122	187557	Bushing Tension Relief
185	73900700	Nut Lock Flange 7/16-14 Gr. 5
187	195161	Stud Fastener w/"D" Anti-Rotation
188	73900500	Nut Lock Hex Flange 5/16-18
189	195185	Arm Susp. Mower Rear
190	196539	Bolt Shoulder
192	198468	Keeper Belt Idler
194	72140716	Bolt Carr Sqnk 3/8-16 x 2-1/4
195	72110622	Bolt RDHD 3/8-16UNC x 2-3/4 Gr.5
- -	187254	High Lift Blade
- -	187292	Mandrel Asm. Service (Includes Key Nos. 13-15 and 33)
- -	197701	Replacement Mower, Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER PBGT22H54 (96042000600)

MOWER LIFT



KEY NO.	PART NO.	DESCRIPTION
2	195223	Shaft Asm., Lift
3	195230	Lever Asm., Lift Rh
7	196492	Grip, Lever
10	196314	Spring Torsion
87	194209	Pin Cotter 7/16 Bow Tie Lock
88	195304	Spring Lift Assist

KEY NO.	PART NO.	DESCRIPTION
89	19191912	Washer Clear Zinc
90	194208	Pin Cotter 5/16 Bow Tie Lock
91	403407	Link Lift Susp Mower Rear
97	17060612	Screw 3/8-16 x .75 Smgml Tap/R.Z
98	195264	Link Lift Susp. Front Mower

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm