
# LF 100

## Spare parts list

### Forward plate

LF 100 s/n BGF000001 –
Engine: Honda GX 160, Hatz 1B20



© 2018 xxxxxxxxxxxxxxxx | No. xxxxxxxxxx | 2018-03

# General information

This spare parts list applies to the following:

| Part number | Description |
|---|---|
| 967876801 | Forward plate LF 100 Honda L 500 mm (19.68 in.) |
| 967876701 | Forward plate LF 100 Honda LA 500 mm (19.68 in.) |
| 967876601 | Forward plate LF 100 Honda LAT 500 mm (19.68 in.) |
| 967882301 | Forward plate LF 100 Hatz L 500 mm (19.68 in.) |
| 967870901 | Forward plate LF 100 Hatz LAT 500 mm (19.68 in.) |

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.
Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

**Instructions for use**
This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.
For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.
Please observe the safety instructions listed in the relevant Safety and operating instructions!

Kits and consumables . . . . . 1

**Preventative Maintenance Kits**

Start Up Kit, Honda . . . . . 3
12 months / 200 hours service kit . . . . . 5
Start Up Kit, Hatz . . . . . 7
12 months / 500 hours service kit . . . . . 9
Six months / Every 250 hours kit . . . . . 11

**Service, repair and wear part kits**

Shock absorber repair kit, Honda . . . . . 13
Shock absorber repair kit, Hatz . . . . . 15
Eccentric element repair kit . . . . . 17
Block paving plate kit 500 mm (19.7 in.) . . . . . 19
Sprinkler system kit . . . . . 21
Fork lifting device kit . . . . . 23
Transport device kit . . . . . 25
Vibration damped handle kit . . . . . 27

**Refurbishment kits**

594214401 CosmeticKit LF 100 Hatz LAT . . . . . 29
595133301 CosmeticKit LF 100 Hatz . . . . . 31
595133701 GoldKit LF 100 Hatz LAT . . . . . 33
595388401 GoldKit LF 100 Hatz . . . . . 35
594215901 CosmeticKit LF 100 Honda LAT . . . . . 37
595388301 GoldKit LF 100 Honda LAT . . . . . 39
595388201 GoldKit LF 100 Honda . . . . . 41
595386401 CosmeticKit LF 100 Honda . . . . . 43
594219301 SilverKit LF 100 Hatz . . . . . 45
594764801 SilverKit LF 100 Honda . . . . . 47
594219301 SilverKit LF 100 Hatz LAT . . . . . 49
594764801 SilverKit_LF_100_Honda_LAT . . . . . 51

**Spare parts list**

Engine plate installation, Honda . . . . . 53
Engine plate installation, Hatz . . . . . 55
Ground plate installation . . . . . 57
Block paving plate 500 mm (19.7 in.) . . . . . 59
Lifting handle . . . . . 61
Transport device, new version . . . . . 63
Transport device, old version . . . . . 65
Sprinkler system . . . . . 67
Fork lifting device . . . . . 69
Engine installation, Honda . . . . . 71
Engine, Honda GX 160 UT2 SXS4 OH . . . . . 73
Engine installation, Hatz . . . . . 76
Engine, Hatz 1B20 manual start . . . . . 79
Fuel tank, Hatz 1B20 . . . . . 84
Transmission cover, Honda . . . . . 87
Transmission cover, Hatz . . . . . 89
Standard handle for Honda and Hatz, old version . . . . . 91
Standard handle for Honda, new version . . . . . 93
Vibration damped handle . . . . . 95
Labels . . . . . 97

Kits and consumables

| Service offers resume LF100 | Item | Number | Description |
|---|---|---|---|
| **Lubricants** | 1 | | Can Paroil E Mission Green 5 Liter/1.32 Gallon |
| | 2 | | Can Paroil E Mission Green 20 Liter/5.3 Gallon |
| | 3 | | Can Paroil E Mission Green 210 Liter/55.5 Gallon |
| **Preventive maintenance** | 4 | 594194101 | One year service kit |
| | 5 | 594194201 | One year service kit |
| **Rebuild&Overhaul kits** | 6 | 594205001 | Vibration damped handle kit |
| | 7 | 594204901 | Transport device kit |
| **Wear&Repair Kits** | 8 | 594194401 | Eccentric element repair kit |
| | 9 | 594194601 | Shock absorber repair kit |
| | 10 | 594194701 | Shock absorber repair kit |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | - | Drum Paroil Mission green 210 Liter/55.5 Gallon | 1 | |
| 2 | - | Can Paroil Mission green 20 Liter/5.3 Gallon | 1 | |
| 3 | - | Drum Paroil Mission green 210 Liter/55.5 Gallon | 1 | |
| 4 | 594194101 | One year service kit | 1 | |
| 5 | 594194201 | One year service kit | 1 | |
| 6 | 594205001 | Vibration damped handle kit | 1 | |
| 7 | 594204901 | Transport device kit | 1 | |
| 8 | 594194401 | Eccentric element repair kit | 1 | |
| 9 | 594194601 | Shock absorber repair kit | 1 | |
| 10 | 594194701 | Shock absorber repair kit | 1 | |

**Preventative Maintenance Kits** Start Up Kit, Honda

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595385301 | Start Up Kit | | |
| 2 | 594216201 | 12 months / 200 hours service kit | 1 | |
| 3 | 594302101 | Air Filter, complete | 1 | |
| 4 | 594488801 | V-belt | 1 | |
| 5 | 594302101 | Air Filter, complete | 1 | |

**Preventative Maintenance Kits** 12 months / 200 hours service kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594216201 | 12 months / 200 hours service kit | 1 | |
| 2 | 594302101 | Air Filter, complete | 1 | |
| 3 | 594488801 | V-belt | 1 | |

**Preventative Maintenance Kits** Start Up Kit, Hatz

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM


| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594218201 | Start Up Kit | 1 | |
| 2 | 594216701 | 12 months / 500 hours service kit | 1 | |
| 3 | 594488901 | V-belt | 1 | |
| 4 | 595377401 | Fuel filter | 1 | |
| 5 | 595377301 | Air Filter | 1 | |
| 6 | 594214601 | Six months / Every 250 hours kit | 1 | |
| 7 | 595377401 | Fuel filter | 1 | |
| 8 | 595377301 | Air Filter | 1 | |

**Preventative Maintenance Kits** 12 months / 500 hours service kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594216701 | 12 months / 500 hours service kit | 1 | |
| 2 | 594488901 | V-belt | 1 | |
| 3 | 595377401 | Fuel filter | 1 | |
| 4 | 595377301 | Air Filter | 1 | |

**Preventative Maintenance Kits** Six months / Every 250 hours kit



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594214601 | Six months / Every 250 hours kit | 1 | |
| 2 | 595377401 | Fuel filter | 1 | |
| 3 | 595377301 | Air Filter | 1 | |

**Service, repair and wear part kits** Shock absorber repair kit, Honda

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594194601 | Shock absorber repair kit | 1 | |
| - | 594341901 | Shock absorber | 4 | A |
| - | 594526401 | Square taper washer | 4 | B |
| Not Shown | - | Nut, M10 A3K, See section "Ground plate installation". | 8 | |
| - | 594480401 | Shock absorber | 2 | C |
| Not Shown | - | Screw, M12 x 50 mm 8.8 A3K , See section "Handle, standard". | 2 | |

Comments for Page: Shock absorber repair kit, Honda

(L)OCAL REMARKS

A | For ground plate

See section "Ground plate installation".

B | See section "Ground plate installation".

C | For handle

See section "Handle, standard".

**Service, repair and wear part kits** Shock absorber repair kit, Hatz

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594194701 | Shock absorber repair kit | 1 | |
| - | 594341901 | Shock absorber | 4 | A |
| Not Shown | - | Nut, M10 A3K, See section "Ground plate installation". | 8 | |
| - | 594480401 | Shock absorber | 2 | B |
| Not Shown | - | Screw, M12 x 50 mm 8.8 A3K , See section "Handle, standard". | 2 | |

Comments for Page: Shock absorber repair kit, Hatz

(L)OCAL REMARKS

A | For ground plate

See section "Ground plate installation".

B | For handle

See section "Handle, standard".

**Service, repair and wear part kits** Eccentric element repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594194401 | Eccentric element repair kit | 1 | |
| 2 | 595185701 | Screw, M8x25mm 8.8 A2K | 1 | |
| 3 | 595187201 | Washer, 8.4x22x3 mm 300HV | 1 | |
| 4 | 595048001 | Lip-type oil seal | 1 | A |
| 5 | 594523301 | Screw, M6x16 mm 8.8 A2K | 6 | |
| 6 | 594526101 | Ball bearing | 2 | B |


Comments for Page: Eccentric element repair kit

(L)OCAL REMARKS

A | See section "Ground plate installation".


B | See section "Ground plate installation".

**Service, repair and wear part kits** Block paving plate kit 500 mm (19.7 in.)




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594868201 | Block paving plate kit | 1 | |
| 2 | 594484801 | Polyurethane plate, 500 mm, 19.7 in. | 1 | |
| 3 | 594484901 | Bracket | 1 | |
| 4 | 595065501 | Nut, M8 x 1.25 mm A2K | 2 | |
| 5 | 595066601 | Washer, 8.4x 6x1.5 mm 300HV | 2 | |
| 6 | 594522501 | Screw, M8 x 75 mm 8.8 A2K | 2 | |

**Service, repair and wear part kits** Sprinkler system kit




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594709601 | Sprinkler system kit | 1 | |
| Not Shown | - | Water Tank | 1 | |
| Not Shown | - | Rod | 1 | |
| Not Shown | - | Handle | 1 | |
| Not Shown | - | Washer, 8.4 x 25 x 2 mm, 0.33 x 0.98 x 0.08 in. | 2 | |
| Not Shown | - | Screw, M8 x 25 mm 8.8 A2K | 1 | |
| Not Shown | - | Nut, M8 -8 DIN985 | 1 | |
| Not Shown | - | Washer, 6.4 x 18 x 1.6 mm, 0.25 x 0.71 x 0.06 in. | 1 | |
| Not Shown | - | Screw, M6 x 16 mm 8.8 A2K | 1 | |
| Not Shown | - | Cap | 1 | |
| Not Shown | - | Instruction label | 1 | |
| Not Shown | - | O-ring, 8 x 3 mm, 0.31 x 0.12 in. (70 shore) | 1 | |
| Not Shown | - | Instruction label | 1 | |

**Service, repair and wear part kits** Fork lifting device kit



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595503101 | Fork lifting device kit | 1 | |
| 2 | 594489901 | Strap | 1 | |
| 3 | 595185701 | Screw, M8x25mm 8.8 A2K | 4 | |
| 4 | 595182701 | Washer, 9 x 25 x 3 mm, 0.35 x 0.98 x 0.12 in. | 8 | |
| 5 | 595064601 | Lock nut, M8x1.25 mm A2K | 8 | |

**Service, repair and wear part kits** Transport device kit



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594709701 | Transport device kit | 1 | |
| Not Shown | - | Wheel bracket | 1 | A |
| Not Shown | - | Wheel bracket | 1 | B |
| Not Shown | - | Washer, 8.4 x 25 x 2 mm, 0.33 x 0.98 x 0.08 in. | 4 | |
| Not Shown | - | Wheel fork | 1 | |
| Not Shown | - | Screw, M8 x 30 mm 8.8 A2K | 2 | |
| Not Shown | - | Nut, M8 A2K | 2 | |
| Not Shown | - | Wheel | 2 | |
| Not Shown | - | Screw, M8 x 12 mm 8.8 A2K | 2 | |
| Not Shown | - | Shock absorber | 1 | |
| Not Shown | - | Hook | 1 | |
| Not Shown | - | Nut, M10 | 1 | |
| Not Shown | - | Washer, 10.5 x 22 x 2 mm, 0.41 x 0.87 x 0.08 in. | 1 | |
| Not Shown | - | Screw, M10 x 20 mm 8.8 FZB | 1 | |
| Not Shown | - | Screw, M8 x 25 mm 8.8 A2K | 4 | |
| Not Shown | - | Screw, M8 x 35 mm 8.8 A2K | 4 | |


Comments for Page: Transport device kit

(L)OCAL REMARKS

A | Left

B | Right

**Service, repair and wear part kits** Vibration damped handle kit



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594205001 | Vibration damped handle kit | 1 | |
| 2 | 594482201 | Bracket | 2 | |
| 3 | 594524701 | Jointing nut, M6 x 30 mm 8.8 | 8 | |
| 4 | 594526701 | Screw, M6 x 12 mm 10.9 A2T | 16 | |
| 5 | 594480501 | Shock absorber | 2 | |
| 6 | 594482101 | Bracket | 2 | |
| 7 | 594166301 | Handle | 1 | |
| 8 | 594525001 | Screw, M5 x 10 mm A2K | 8 | |
| 9 | 594526601 | Washer, 6.4x18x1.6 mm A2T | 16 | |

**Refurbishment kits** 594214401 CosmeticKit LF 100 Hatz LAT

| | | | |
|---|---|---|---|
| 1 | **594214401** | **Cosmetic Kit** | |
| 2 | **Covers** | Belt guard | 1 |
| 3 | | Bolt | 2 |
| 4 | | Washer | 2 |
| 5 | | Screw | 2 |
| 6 | | Lock Spring | 2 |
| 7 | | Bolt | 1 |
| 8 | | Nut | 1 |
| 9 | | Bolt | 2 |
| 10 | | Sprinkler Water System | 1 |
| 11 | **Handle** | Handle Kit | 1 |
| 12 | **Labeling** | Product Lable Set | **1** |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594214401 | 200 Hours Service Kit / 12 Months Service Kit | 1 | |
| 2 | - | Belt guard | 1 | |
| 3 | - | Bolt | 2 | |
| 4 | - | Washer | 2 | |
| 5 | - | Screw | 2 | |
| 6 | - | Lock Spring | 2 | |
| 7 | - | Bolt | 1 | |
| 8 | - | Nut | 1 | |
| 9 | - | Bolt | 2 | |
| 10 | - | Sprinkler Water System | 1 | |
| 11 | - | Handle Kit | 1 | |
| 12 | - | Product Label Set | 1 | |

**Refurbishment kits** 595133301 CosmeticKit LF 100 Hatz

| | | | |
|---|---|---|---|
| 1 | **595133301** | **Cosmetic Kit** | |
| 2 | Covers | Cover | 1 |
| 3 | | Belt guard | 1 |
| 4 | | Bolt | 2 |
| 5 | | Washer | 2 |
| 6 | | Screw | 2 |
| 7 | | Lock Spring | 2 |
| 8 | | Bolt | 1 |
| 9 | | Nut | 1 |
| 10 | | Bolt | 2 |
| 11 | Handle | Handle Kit | 1 |
| 12 | Labeling | Product Label Set | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595133301 | Cosmetic Kit | 1 | |
| 2 | - | Cover | 1 | |
| 3 | - | Belt guard | 1 | |
| 4 | - | Bolt | 2 | |
| 5 | - | Washer | 2 | |
| 6 | - | Screw | 2 | |
| 7 | - | Lock Spring | 2 | |
| 8 | - | Bolt | 1 | |
| 9 | - | Nut | 1 | |
| 10 | - | Bolt | 2 | |
| 11 | - | Handle Kit | 1 | |
| 12 | - | Product Label Set | 1 | |

**Refurbishment kits** 595133701 GoldKit LF 100 Hatz LAT

| | | | |
|---|---|---|---|
| 1 | **594219101** | **Gold Kit LF 100 Hatz LAT** | |
| | | **Ground Plate and Eccentric System** | |
| 2 | Eccentric System | Eccentric Element Repair Kit | 1 |
| 3 | | V-Belt Pulley | 1 |
| 4 | | Centrifugal Clutch | 1 |
| 5 | | Screw | |
| 6 | | Lock Washer | 6 |
| 7 | | Shock absorber repair kit | 1 |
| | | **Cosmetic Kit** | |
| 8 | Covers | Belt guard | 1 |
| 9 | | Bolt | 2 |
| 10 | | Washer | 2 |
| 11 | | Screw | 2 |
| 12 | | Lock Spring | 2 |
| 13 | | Bolt | 1 |
| 14 | | Nut | 1 |
| 15 | | Bolt | 2 |
| 16 | | Sprinkler Water System | 1 |
| 17 | Handle | Handle Kit | 1 |
| 18 | Labeling | Product Label Set | 1 |
| | | **Engine** | |
| 19 | Service Kit | Yearly Service Kit | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594219101 | Silver Kit LF 75 LAT | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Centrifugal Clutch | 1 | |
| 5 | - | Screw | 6 | |
| 6 | - | Lock Washer | 6 | |
| 7 | - | Shock absorber repair kit | 1 | |
| - | -- | Cosmetic Kit | 1 | |
| 8 | - | Belt guard | 1 | |
| 9 | - | Bolt | 2 | |
| 10 | - | Washer | 2 | |
| 11 | - | Screw | 2 | |
| 12 | - | Lock Spring | 2 | |
| 13 | - | Bolt | 1 | |
| 14 | - | Nut | 1 | |
| 15 | - | Bolt | 2 | |
| 16 | - | Sprinkler Water System | 1 | |
| 17 | - | Handle Kit | 1 | |
| 18 | - | Product Label Set | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 19 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 595388401 GoldKit LF 100 Hatz

| | | | |
|---|---|---|---|
| 1 | **595388401** | **Gold Kit LF 100 Hatz** | |
| | | **Ground Plate and Eccentric System** | |
| 2 | Eccentric System | Eccentric Element Repair Kit | 1 |
| 3 | | V-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Centrifugal Clutch | 1 |
| 6 | | Lock Washer | 6 |
| 7 | | Shock absorber repair kit | 1 |
| | | **Cosmetic Kit** | |
| 8 | Covers | Cover | 1 |
| 9 | | Belt guard | 1 |
| 10 | | Bolt | 2 |
| 11 | | Washer | 2 |
| 12 | | Screw | 2 |
| 13 | | Lock Spring | 2 |
| 14 | | Bolt | 1 |
| 15 | | Nut | 1 |
| 16 | | Bolt | 2 |
| 17 | Handle | Handle Kit | 1 |
| 18 | Labeling | Product Label Set | 1 |
| | | **Engine** | |
| 19 | Service Kit | Yearly Service Kit | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595388401 | Gold Kit LF 100 Hatz | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Centrifugal Clutch | 1 | |
| 6 | - | Lock Washer | 6 | |
| 7 | - | Shock absorber repair kit | 1 | |
| - | -- | Cosmetic Kit | 1 | |
| 8 | - | Cover | 1 | |
| 9 | - | Belt guard | 1 | |
| 10 | - | Bolt | 2 | |
| 11 | - | Washer | 2 | |
| 12 | - | Screw | 2 | |
| 13 | - | Lock Spring | 2 | |
| 14 | - | Bolt | 1 | |
| 15 | - | Nut | 1 | |
| 16 | - | Bolt | 2 | |
| 17 | - | Handle Kit | 1 | |
| 18 | - | Product Label Set | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 19 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 594215901 CosmeticKit LF 100 Honda LAT

| | | | |
|---|---|---|---|
| 1 | **594215901** | **Cosmetic Kit** | |
| 2 | **Covers** | Belt guard | 1 |
| 3 | | Screw | 3 |
| 4 | | Nut | 1 |
| 5 | | Screw | 3 |
| 6 | | Screw | 1 |
| 7 | | Lock spring | 1 |
| 8 | | Washer | 3 |
| 9 | | Screw | 2 |
| 10 | | Sprinkler Water System | 1 |
| 11 | **Handle** | Handle Kit | 1 |
| 12 | **Labeling** | Product Lable Set | **1** |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594215901 | 200 Hours Service Kit / 12 Months service Kit | 1 | |
| 2 | - | Belt guard, outer | 1 | |
| 3 | - | Screw | 3 | |
| 4 | - | Nut | 1 | |
| 5 | - | Screw | 3 | |
| 6 | - | Screw | 1 | |
| 7 | - | Lock Spring | 1 | |
| 8 | - | Washer | 3 | |
| 9 | - | Screw | 2 | |
| 10 | - | Sprinkler Water System | 1 | |
| 11 | - | Handle Kit | 1 | |
| 12 | - | Product Label Set | 1 | |

**Refurbishment kits** 595388301 GoldKit LF 100 Honda LAT

| | | | |
|---|---|---|---|
| 1 | **595388301** | **Gold Kit LF 100 Honda LAT** | |
| | | **Ground Plate and Eccentric System** | |
| 2 | Eccentric System | Eccentric Element Repair Kit | 1 |
| 3 | | V-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Lock Washer | 6 |
| 6 | | Shock absorber repair kit | 1 |
| | | **Cosmetic Kit** | |
| 7 | Covers | Belt guard, outer | 1 |
| 8 | | Screw | 3 |
| 9 | | Nut | 1 |
| 10 | | Screw | 3 |
| 11 | | Screw | 1 |
| 12 | | Lock Spring | 1 |
| 13 | | Washer | 3 |
| 14 | | Screw | 2 |
| 15 | | Sprinkler Water System | 1 |
| 16 | Handle | Handle Kit | 1 |
| 17 | Labeling | Product Label Set | 1 |
| | | **Engine** | |
| 18 | Service Kit | Yearly Service Kit | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595388301 | Gold Kit LF 100 Honda LAT | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Lock Washer | 6 | |
| 6 | - | Shock absorber repair kit | 1 | |
| - | -- | Cosmetic Kit | 1 | |
| 7 | - | Belt guard, outer | 1 | |
| 8 | - | Screw | 3 | |
| 9 | - | Nut | 1 | |
| 10 | - | Screw | 3 | |
| 11 | - | Screw | 1 | |
| 12 | - | Lock Spring | 1 | |
| 13 | - | Washer | 3 | |
| 14 | - | Screw | 2 | |
| 15 | - | Sprinkler Water System | 1 | |
| 16 | - | Handle Kit | 1 | |
| 17 | - | Product Label Set | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 18 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 595388201 GoldKit LF 100 Honda

| | | | |
|---|---|---|---|
| 1 | **595388201** | **Gold Kit LF 100 Honda** | |
| | | **Ground Plate and Eccentric System** | |
| 2 | Eccentric System | Eccentric Element Repair Kit | 1 |
| 3 | | V-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Lock Washer | 6 |
| 6 | | Shock absorber repair kit | 1 |
| | | **Cosmetic Kit** | |
| 7 | Covers | Cover | 1 |
| 8 | | Belt guard, outer | 1 |
| 9 | | Screw | 3 |
| 10 | | Nut | 1 |
| 11 | | Screw | 3 |
| 12 | | Screw | 1 |
| 13 | | Lock Spring | 1 |
| 14 | | Washer | 3 |
| 15 | | Screw | 2 |
| 16 | Handle | Handle Kit | 1 |
| 17 | Labeling | Product Label Set | 1 |
| | | **Engine** | |
| 18 | Service Kit | Yearly Service Kit | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595388201 | Gold Kit LF 100 Honda | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Lock Washer | 6 | |
| 6 | - | Shock absorber repair kit | 1 | |
| - | -- | Cosmetic Kit | 1 | |
| 7 | - | Cover | 1 | |
| 8 | - | Belt guard, outer | 1 | |
| 9 | - | Screw | 3 | |
| 10 | - | Nut | 1 | |
| 11 | - | Screw | 3 | |
| 12 | - | Screw | 1 | |
| 13 | - | Lock Spring | 1 | |
| 14 | - | Washer | 3 | |
| 15 | - | Screw | 2 | |
| 16 | - | Handle Kit | 1 | |
| 17 | - | Product Label Set | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 18 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 595386401 CosmeticKit LF 100 Honda

| | | | |
|---|---|---|---|
| 1 | **595386401** | **Cosmetic Kit** | |
| 2 | Covers | Cover | 1 |
| 3 | | Belt guard, outer | 1 |
| 4 | | Screw | 3 |
| 5 | | Nut | 1 |
| 6 | | Screw | 3 |
| 7 | | Screw | 1 |
| 8 | | Lock Spring | 1 |
| 9 | | Washer | 3 |
| 10 | | Screw | 2 |
| 11 | Handle | Handle Kit | 1 |
| 12 | Labeling | Product Label Set | 1 |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595386401 | Cosmetic Kit | 1 | |
| 2 | - | Cover | 1 | |
| 3 | - | Belt guard, outer | 1 | |
| 4 | - | Screw | 3 | |
| 5 | - | Nut | 1 | |
| 6 | - | Screw | 3 | |
| 7 | - | Screw | 1 | |
| 8 | - | Lock Spring | 1 | |
| 9 | - | Washer | 3 | |
| 10 | - | Screw | 2 | |
| 11 | - | Handle Kit | 1 | |
| 12 | - | Product Label Set | 1 | |

**Refurbishment kits** 594219301 SilverKit LF 100 Hatz

| | | | |
|---|---|---|---|
| 1 | **594219301** | **Silver Kit LF 100 Hatz** | |
| | **Ground Plate and Eccentric System** | | |
| 2 | **Eccentric system** | Eccentric Element Repair Kit | 1 |
| 3 | | v-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Centrifugal Clutch | 1 |
| 6 | | Lock Washer | 6 |
| 7 | | Shock absorber repair kit | 1 |
| | **Engine** | | |
| 8 | **Service Kit** | Yearly Service Kit | **1** |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594219301 | Silver Kit LF 100 Hatz | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Centrifugal Clutch | 1 | |
| 6 | - | Lock Washer | 6 | |
| 7 | - | Shock absorber repair kit | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 8 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 594764801 SilverKit LF 100 Honda

| | | | |
|---|---|---|---|
| 1 | **594764801** | **Silver Kit LF 100 Hatz** | |
| | **Ground Plate and Eccentric System** | | |
| 2 | **Eccentric system** | Eccentric Element Repair Kit | 1 |
| 3 | | v-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Lock Washer | 6 |
| 6 | | Shock absorber repair kit | 1 |
| | **Engine** | | |
| 7 | **Service Kit** | Yearly Service Kit | **1** |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594764801 | Silver Kit LF 100 Honda | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Lock Washer | 6 | |
| 6 | - | Shock absorber repair kit | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 7 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 594219301 SilverKit LF 100 Hatz LAT

| | | | |
|---|---|---|---|
| 1 | **594219301** | **Silver Kit LF 100 Hatz** | |
| | **Ground Plate and Eccentric System** | | |
| 2 | **Eccentric system** | Eccentric Element Repair Kit | 1 |
| 3 | | v-Belt Pulley | 1 |
| 4 | | Centrifugal Clutch | 1 |
| 5 | | Screw | 6 |
| 6 | | Lock Washer | 6 |
| 7 | | Shock absorber repair kit | 1 |
| | **Engine** | | |
| 8 | **Service Kit** | Yearly Service Kit | **1** |


| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594219301 | Silver Kit LF 100 Hatz | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Centrifugal Clutch | 1 | |
| 5 | - | Screw | 6 | |
| 6 | - | Lock Washer | 6 | |
| 7 | - | Shock absorber repair kit | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 8 | - | Yearly Service Kit | 1 | |

**Refurbishment kits** 594764801 SilverKit_LF_100_Honda_LAT

| | | | |
|---|---|---|---|
| 1 | **594764801** | **Silver Kit LF 100 Honda LAT** | |
| | **Ground Plate and Eccentric System** | | |
| 2 | **Eccentric system** | Eccentric Element Repair Kit | 1 |
| 3 | | v-Belt Pulley | 1 |
| 4 | | Screw | 6 |
| 5 | | Lock Washer | 6 |
| 6 | | Shock absorber repair kit | 1 |
| | **Engine** | | |
| 7 | **Service Kit** | Yearly Service Kit | **1** |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594764801 | Silver Kit LF 100 Honda | 1 | |
| - | -- | Ground Plate and Eccentric System | 1 | |
| 2 | - | Eccentric Element Repair Kit | 1 | |
| 3 | - | V-Belt Pulley | 1 | |
| 4 | - | Screw | 6 | |
| 5 | - | Lock Washer | 6 | |
| 6 | - | Shock absorber repair kit | 1 | |
| - | -- | Engine and Transmission | 1 | |
| 7 | - | Yearly Service Kit | 1 | |

**Spare parts list** Engine plate installation, Honda



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595185701 | Screw, M8x25mm 8.8 A2K | 7 | |
| 2 | 594144601 | Protective frame | 1 | |
| 3 | 594145201 | Cover | 1 | |
| 4 | 594145401 | Engine plate | 1 | |
| 5 | 594526401 | Square taper washer | 2 | A |


Comments for Page: Engine plate installation, Honda

A: Flat machined surface. B: Round machined surface.

(L)OCAL REMARKS


A | For engine plate with flat machined contact surface for washers.

**Spare parts list** Engine plate installation, Hatz




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595185701 | Screw, M8x25mm 8.8 A2K | 7 | |
| 2 | 594144701 | Protective frame | 1 | |
| 3 | 594145301 | Cover | 1 | |
| 4 | 594145501 | Engine plate | 1 | |

**Spare parts list** Ground plate installation




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594650901 | Ground plate | 1 | |
| 2 | 594643901 | Eccentric shaft | 1 | |
| 3 | 594526101 | Ball bearing | 2 | |
| 4 | 594490101 | Cover | 1 | |
| 5 | 594128301 | Lip-type oil seal | 1 | |
| 6 | 594486701 | V-belt pulley | 1 | |
| 7 | 594123401 | Washer, 8.4 x 16 x 1.5 mm, 0.33 x 0.63 x 0.06 in. 300 HV | 1 | |
| 8 | 594120001 | Screw, M8 x 25 mm 8.8 A2K | 1 | |
| 9 | 595033201 | Hex. head screw | 6 | |
| 10 | 594490201 | Cover | 1 | |
| 11 | 594341901 | Shock absorber | 4 | |
| 12 | - | Nut, M10 x 1.5 mm GEOMET® | 8 | |
| 13 | 594653201 | Sprinkler bar, 500 mm, 19.7 in. | 1 | |
| 14 | - | Lock nut, M8 x 1.25 mm A2K | 3 | |
| 15 | - | Screw, M8 x 55 mm 8.8 A2K | 2 | |
| 16 | - | Screw, M8 x 45 mm 8.8 A2K | 1 | |
| 17 | 594124601 | Lock washer | 6 | |

**Spare parts list** Block paving plate 500 mm (19.7 in.)



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594484801 | Polyurethane plate, 500 mm, 19.7 in. | 1 | |
| 2 | 594484901 | Bracket | 1 | |
| 3 | 595065501 | Nut, M8 x 1.25 mm A2K | 2 | |
| 4 | 595066601 | Washer, 8.4x 6x1.5 mm 300HV | 2 | |
| 5 | 594522501 | Screw, M8 x 75 mm 8.8 A2K | 2 | |

**Spare parts list** Lifting handle



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594486801 | Handle | 1 | A |
| 2 | 594486901 | Handle | 1 | B |
| 3 | 595179401 | Screw, M8x20 mm 8.8 A2K | 4 | |


Comments for Page: Lifting handle

(L)OCAL REMARKS

A | Right

B | Left

**Spare parts list** Transport device, new version



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594648701 | Bracket | 1 | A |
| 2 | 594648901 | Bracket | 1 | B |
| 3 | 595061001 | Washer, 8,4x25x2 mm | 4 | |
| 4 | 594648801 | Fork | 1 | |
| 5 | 595466601 | Screw, M8x30 mm 8.8 A2K | 2 | |
| 6 | 595064601 | Lock nut, M8x1.25 mm A2K | 2 | |
| 7 | 594455501 | Wheel | 2 | |
| 8 | 595053901 | Hex. screw | 2 | |
| 9 | 594462701 | Shock absorber | 1 | |
| 10 | 594651001 | Hook | 1 | |
| 11 | 595064701 | Nut, M10 | 1 | |
| 12 | 595066701 | plain washer | 1 | |
| 13 | 595055201 | Screw, M10x20 mm 8.8 A3K | 1 | |
| 14 | 595185701 | Screw, M8x25mm 8.8 A2K | 4 | |


Comments for Page: Transport device, new version

(L)OCAL REMARKS

A | left

B | Right

**Spare parts list** Transport device, old version



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594145801 | Fork | 1 | |
| 2 | 594455501 | Wheel | 2 | |
| 3 | 595061001 | Washer, 8,4x25x2 mm | 4 | |
| 4 | 594485101 | Lock | 2 | |
| 5 | 594145601 | Bracket | 1 | A |
| 6 | 594145701 | Bracket | 1 | B |
| 7 | 595185801 | Screw, M8 x 35 mm 8.8 | 4 | |
| 8 | 595053901 | Hex. screw | 2 | |
| 9 | 595064501 | Nut | 8 | C |
| 10 | 595466301 | Screw, M6-1,0x25 mm 8.8 | 4 | |
| 11 | 595068501 | Pipe clamp | 4 | |
| 12 | 594646001 | Stop | 2 | |
| 13 | 594499001 | Screw, M6x30 mm 8.8 A2K | 4 | |
| 14 | 595064601 | Lock nut, M8x1.25 mm A2K | 2 | |
| 15 | 595466601 | Screw, M8x30 mm 8.8 A2K | 2 | |

Comments for Page: Transport device, old version


(L)OCAL REMARKS

A | Left

B | Right


C | M 6

**Spare parts list** Sprinkler system




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594144501 | Water tank | 1 | |
| 2 | 594212301 | Valve rod, complete | 1 | |
| 3 | 594127901 | O-ring, 15 x 4 mm | 1 | |
| 4 | - | Valve rod | 1 | |
| 5 | 594128001 | O-ring, 8 x 2.5 mm | 1 | |
| 6 | 595465701 | Screw, M6x16 mm 8.8 A2K | 1 | |
| 7 | 595061001 | Washer, 8,4x25x2 mm | 2 | |
| 8 | 595062701 | Nut, M8 -8 DIN985 | 1 | |
| 9 | 594483301 | Label | 1 | |
| 10 | 594481401 | Cap | 1 | |
| 11 | 595465901 | Screw, M8x25 mm 8.8 A2K | 1 | |
| 12 | 595069601 | Washer, 6.4x18x1.6 mm | 1 | |
| 13 | 594481101 | Handle | 1 | |

**Spare parts list** Fork lifting device



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594489901 | Strap | 2 | |
| 2 | 595185701 | Screw, M8x25mm 8.8 A2K | 4 | |
| 3 | 595182701 | Washer, 9 x 25 x 3 mm, 0.35 x 0.98 x 0.12 in. | 8 | |
| 4 | 595064601 | Lock nut, M8x1.25 mm A2K | 4 | |

**Spare parts list** Engine installation, Honda




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594329901 | Engine, Honda GX160UT2 SXS4 SD | 1 | A |
| 2 | 595068001 | Washer, 8.4x26x4 mm 300 HV | 4 | |
| 3 | 594484201 | Washer | 4 | |
| 4 | 594499101 | Screw, M8x50 mm 8.8 A2K | 4 | |
| 5 | 595064601 | Lock nut, M8x1.25 mm A2K | 4 | |
| 6 | 595177601 | Stiffener | 1 | |
| 7 | - | Blind rivet, 6.4 x 12 mm , 0.25 x 0.47 in. | 1 | |
| 8 | 595185701 | Screw, M8x25mm 8.8 A2K | 1 | |
| 9 | 595185701 | Screw, M8x25mm 8.8 A2K | 1 | |
| 10 | 594480101 | Centrifugal clutch | 1 | |
| 11 | 594488801 | V-belt | 1 | |

Comments for Page: Engine installation, Honda

(L)OCAL REMARKS

A | Honda GX160UT2 SXS4 SD

**Spare parts list** Engine, Honda GX 160 UT2 SXS4 OH



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594329901 | Engine, Honda GX160UT2 SXS4 SD | 1 | |
| 2 | 594203601 | Silencer | 1 | |
| 3 | 594204101 | Gasket | 1 | |
| 4 | 594300401 | Gasket, muffler | 1 | |
| 5 | 594204001 | Plug, spark (bpr6es) (ngk) | 1 | |
| 6 | 594203801 | Cap assy., oil filler | 1 | |
| 7 | 594203901 | Gasket | 1 | |
| 8 | 595471101 | Cover comp., head | 1 | |
| 9 | 595048801 | Gasket | 1 | |
| 10 | 594204601 | Fuel cap | 1 | |
| 11 | 594204501 | Fuel tank | 1 | |
| 12 | 594204401 | Switch assy., engine stop | 1 | |
| 13 | 595452801 | Oil plug | 1 | |
| 14 | 595048901 | Oil plug gasket | 1 | |
| 15 | -- | Engine part | 1 | |
| 16 | 594572601 | Gasket | 1 | |
| 17 | 594203701 | Carburetor | 1 | |
| 18 | 595070001 | Spacer | 1 | |
| 19 | 595049301 | Nut | 1 | |
| 20 | 595049201 | Cover | 1 | |
| 21 | 595049301 | Nut | 1 | |
| 22 | 595049401 | Grommet | 1 | |
| 23 | 594302101 | Air Filter, complete | 1 | A |
| 24 | 594582401 | Air filter housing | 1 | |
| 25 | 594300201 | Muffler cover, upper | 1 | |
| 26 | 594300601 | Recoil starter, cpl | 1 | B, E |
| 27 | 594304501 | Screw | 1 | |
| 28 | 594304401 | Guide | 1 | |
| 29 | 594304201 | Ratchet | 2 | B |
| 30 | 594304101 | Spring | 2 | |
| 31 | 594304301 | Friction spring | 1 | B |
| 32 | 594304001 | Reel | 1 | |
| 33 | --- | Housing | 1 | |
| 34 | 594303901 | Spring | 1 | |
| 35 | 594304801 | Grip, starter | 1 | |
| 36 | 595049101 | Starting rope | 1 | |
| 37 | 594204801 | Starter assy., recoil *nh1* | 1 | C, D |
| 38 | 595381301 | Adjustment screw | 1 | C |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 39 | 594304401 | Guide | 1 | |
| 40 | 594204201 | Ratchet | 2 | C |
| 41 | 594304101 | Spring | 2 | |
| 42 | 595131001 | Friction washer | 1 | C |
| 43 | 594204301 | Reel | 1 | C |
| 44 | --- | Housing | 1 | |
| 45 | 594303901 | Spring | 1 | |
| 46 | 594304801 | Grip, starter | 1 | |
| 47 | 595049101 | Starting rope | 1 | |
| 48 | 594204701 | Friction spring | 1 | J |

Comments for Page: Engine, Honda GX 160 UT2 SXS4 OH

(L)OCAL REMARKS

A | Delivered with outer and inner filter.

B | Valid up to engine serial number 1411005.


C | Valid from engine serial number 1411006.

D | Black

E | Red


This page intentionally left blank

**Spare parts list** Engine installation, Hatz



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595177301 | Engine | 1 | |
| 2 | 594480001 | Centrifugal clutch | 1 | |
| 3 | - | Washer, 8.4 x 22 x 3 mm 300 HV, 0.33 x 1.02 x 0.16 in. 300 HV | 1 | |
| 4 | - | Screw, M8 x 25 mm 8.8 A2K | 1 | |
| 5 | - | Washer, 8.4 x 22 x 3 mm 300 HV, 0.33 x 1.02 x 0.16 in. 300 HV | 4 | |
| 6 | - | Screw, M8 x 35 mm 8.8 A2K | 4 | |
| 7 | - | Lock nut, M8 x 1.25 mm A2K | 4 | |
| 8 | 594484201 | Washer | 4 | |
| 9 | 594488901 | V-belt | 1 | |

**Spare parts list** Engine, Hatz 1B20 manual start



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595177301 | Engine | 1 | |
| 2 | - | Fuel tank | 1 | |
| 3 | 594570101 | Oil strainer, cpl | 1 | |
| 4 | -- | Tube | 1 | |
| 5 | -- | Oil strainer | 1 | |
| 6 | 595380601 | O-ring | 1 | |
| 7 | 595380701 | Washer | 2 | |
| 8 | -- | Screw, M6 x 16 mm | 1 | |
| 9 | 594570201 | Plug | 1 | |
| 10 | 594513001 | Washer | 1 | |
| 11 | 594570401 | Exhaust pipe | 1 | |
| 12 | 594568401 | Recoil starter, cpl | 1 | |
| 13 | 594569901 | Starter pulley | 1 | |
| 14 | -- | Screw, M6 x 18 mm | 1 | |
| 15 | -- | Washer, M6 | 1 | |
| 16 | 594569201 | Spring | 1 | |
| 17 | -- | Spring washer, M6 | 1 | |
| 18 | -- | Screw, M6 x 10 mm | 1 | |
| 19 | 594569301 | Friction plate | 1 | |
| 20 | 594569701 | O-ring | 1 | |
| 21 | 594569101 | Reel | 1 | |
| 22 | 594569601 | Ratchet | 1 | |
| 23 | --- | Start pulley | 1 | |
| 24 | 594568501 | Handle, complete | 1 | |
| 25 | 594202401 | Sleeve | 1 | |
| 26 | - | Handle | 1 | |
| 27 | 594202501 | Washer, 5.3 mm,  0.21 in. | 1 | |
| 28 | 594568601 | Spiral spring | 1 | |
| 29 | 594568701 | Housing | 1 | |
| 30 | -- | Washer, M6 | 4 | |
| 30 | -- | Washer, M6 | 4 | |
| 30 | -- | Washer, M6 | 4 | |
| 30 | -- | Washer, M6 | 4 | |
| 31 | -- | Screw, M6 | 4 | |
| 32 | 594569001 | Starting rope | 1 | |
| 33 | 594202701 | Air filter housing, complete | 1 | |
| 34 | 594572101 | Vent nipple | 1 | |
| 35 | -- | Housing | 1 | |


| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 36 | 595380801 | Sealing strip | 1 | |
| 37 | 594604301 | Sealing strip | 1 | |
| 38 | 595377301 | Air Filter | 1 | |
| 39 | -- | Valve plate | 1 | |
| 40 | -- | Valve plate | 1 | |
| 40 | -- | Valve plate | 1 | |
| 40 | -- | Valve plate | 1 | |
| 40 | -- | Valve plate | 1 | |
| 41 | 594202601 | Rubber sleeve | 1 | |
| 42 | 594572001 | Gasket | 2 | |
| 43 | 595470201 | Gasket | 1 | |
| 44 | - | Tube | 3 | |
| 45 | - | Washer, M8 | 2 | |
| 46 | 594570901 | Washer | 1 | |
| 47 | 594571201 | Nut | 1 | |
| 48 | 594571301 | Protecting cover | 1 | |
| 49 | 594571401 | Rubber sleeve | 1 | |
| 50 | 595380901 | Shim | 1 | |
| 51 | - | Rivet | 1 | |
| 52 | 594571601 | Plate | 1 | |
| 53 | 594571701 | Rubber hose | 1 | |
| 54 | 594571601 | Plate | 1 | |
| 55 | 594578001 | Oil dipstick | 1 | |
| 56 | -- | Dipstick | 1 | |
| 57 | 594605501 | O-ring | 1 | |
| 58 | 594202801 | Injection pump, complete | 1 | |
| 59 | 595472301 | Injection pump, complete | 1 | |
| 60 | 594761001 | Injection pump, complete | 1 | |
| 61 | 594584701 | Injection pump cpl | 1 | |
| 62 | -- | Pump part | 1 | |
| 63 | -- | Pump part | 1 | |
| 63 | -- | Pump part | 1 | |
| 64 | -- | Pump part | 1 | |
| 63 | -- | Pump part | 1 | |
| 65 | -- | Pump part | 1 | |
| 64 | -- | Pump part | 1 | |
| 66 | -- | Pump part | 1 | |
| 64 | -- | Pump part | 1 | |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 67 | -- | Pump part | 1 | |
| 65 | -- | Pump part | 1 | |
| 68 | -- | Pump part | 1 | |
| 65 | -- | Pump part | 1 | |
| 69 | -- | Pump part | 1 | |
| 66 | -- | Pump part | 1 | |
| 70 | -- | Pump part | 1 | |
| 66 | -- | Pump part | 1 | |
| 71 | -- | Pump part | 1 | |
| 67 | -- | Pump part | 1 | |
| 67 | -- | Pump part | 1 | |
| 68 | -- | Pump part | 1 | |
| 68 | -- | Pump part | 1 | |
| 69 | -- | Pump part | 1 | |
| 69 | -- | Pump part | 1 | |
| 70 | -- | Pump part | 1 | |
| 70 | -- | Pump part | 1 | |
| 71 | -- | Pump part | 1 | |
| 71 | -- | Pump part | 1 | |
| 81 | -- | Injector part | 1 | |
| 72 | 595190301 | O-ring 0,2 mm | 1 | |
| 82 | -- | Injector part | 1 | |
| 73 | 594568001 | O-ring 0,3 mm | 1 | |
| 83 | -- | Injector part | 1 | |
| 74 | 594568101 | O-ring 0,4 mm | 1 | |
| 84 | -- | Injector part | 1 | |
| 75 | 594568201 | O-ring 0,5 mm | 1 | |
| 85 | -- | Injector part | 1 | |
| 76 | 594568301 | O-ring 0,6 mm | 1 | |
| 86 | -- | Injector part | 1 | |
| 77 | 594202901 | Injector, complete | 1 | |
| 87 | -- | Injector part | 1 | |
| 78 | 594853501 | Injector, complete | 1 | |
| 88 | -- | Injector part | 1 | |
| 79 | 595471701 | Injector, complete | 1 | |
| 89 | -- | Injector part | 1 | |
| 80 | -- | Injector part | 1 | |
| 90 | -- | Injector part | 1 | |

| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 81 | -- | Injector part | 1 | |
| 91 | -- | Injector part | 1 | |
| 81 | -- | Injector part | 1 | |
| 92 | -- | Injector part | 1 | |
| 82 | -- | Injector part | 1 | |
| 93 | -- | Injector part | 1 | |
| 82 | -- | Injector part | 1 | |
| 83 | -- | Injector part | 1 | |
| 83 | -- | Injector part | 1 | |
| 84 | -- | Injector part | 1 | |
| 84 | -- | Injector part | 1 | |
| 85 | -- | Injector part | 1 | |
| 85 | -- | Injector part | 1 | |
| 86 | -- | Injector part | 1 | |
| 86 | -- | Injector part | 1 | |
| 87 | -- | Injector part | 1 | |
| 87 | -- | Injector part | 1 | |
| 88 | -- | Injector part | 1 | |
| 88 | -- | Injector part | 1 | |
| 89 | -- | Injector part | 1 | |
| 89 | -- | Injector part | 1 | |
| 90 | -- | Injector part | 1 | |
| 90 | -- | Injector part | 1 | |
| 91 | -- | Injector part | 1 | |
| 91 | -- | Injector part | 1 | |
| 92 | -- | Injector part | 1 | |
| 92 | -- | Injector part | 1 | |
| 93 | -- | Injector part | 1 | |
| 93 | -- | Injector part | 1 | |
| 94 | 595193601 | Silencer, complete | 1 | |
| 95 | -- | Silencer | 1 | |
| 96 | 595192601 | Gasket | 1 | |
| 97 | -- | Screw, M8 x 25 mm | 1 | |
| 98 | -- | Washer, M8 | 1 | |
| 99 | 595381001 | Hook | 1 | |
| 100 | 595381101 | Cover | 1 | |


This page intentionally left blank

**Spare parts list** Fuel tank, Hatz 1B20




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594203001 | Fuel tank, complete | 1 | |
| 2 | 594566101 | Fuel cap | 1 | |
| 3 | --- | Cap | 1 | |
| 4 | --- | Gasket | 1 | |
| 5 | 595381201 | Circlip | 1 | |
| 6 | 594203501 | Rope | 1 | |
| 7 | 595377401 | Fuel filter | 1 | |
| 8 | --- | Filter element | 1 | |
| 9 | --- | Pipe | 1 | |
| 10 | 594567001 | Gasket | 1 | |
| 11 | 594203401 | Fuel hose | 1 | |
| 12 | 594566301 | Ventilation valve | 1 | |
| 13 | 594567601 | Hose clamp | 1 | |
| 14 | 594566401 | Adapter | 1 | |
| 15 | 594566501 | Gasket | 2 | |
| 16 | 595191601 | Rubber sleeve | 1 | |
| 17 | 594567001 | Gasket | 1 | |
| 18 | 594567101 | Pipe | 1 | |
| 19 | -- | Fuel tank | 1 | |
| 20 | -- | Label | 1 | |
| 21 | 594605201 | Nipple | 1 | |
| 22 | 595192701 | Nipple | 1 | |
| 23 | -- | Nipple | 1 | |
| 24 | -- | Joint | 1 | |
| 25 | 594203301 | Ventilating screw | 1 | |
| 26 | 594203201 | Nipple | 1 | |
| 27 | 594203101 | Clamp | 1 | |
| 28 | 594583201 | Water separator, cpl | 1 | |
| 29 | -- | Hose | 1 | |
| 30 | -- | Hose clip | 1 | |
| 31 | -- | Water separator | 1 | |
| 32 | -- | Drain screw | 1 | |
| 33 | 594601901 | Fuel filter | 1 | |

**Spare parts list** Transmission cover, Honda




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594145001 | Belt guard, inner | 1 | |
| 2 | 594483101 | Belt guard, outer | 1 | |
| 3 | 594120001 | Screw, M8 x 25 mm 8.8 A2K | 3 | |
| 4 | 595065501 | Nut, M8 x 1.25 mm A2K | 1 | |
| 5 | 594119801 | Flange screw | 3 | |
| 6 | 594648001 | Screw, M8 x 25 mm 8.8 A2K | 1 | |
| 7 | 594650201 | Lock spring | 1 | |
| 8 | 594647801 | Washer | 3 | |
| 9 | 594746701 | Screw, M8 x 20 mm 8.8 A2K | 2 | |

**Spare parts list** Transmission cover, Hatz




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594145101 | Belt guard | 1 | |
| 2 | 594483901 | Belt guard, inner | 1 | |
| 3 | - | Screw, M8 x 25 mm 8.8 A2K | 1 | |
| 4 | - | Screw, M10 x 25 mm 8.8 A3K | 2 | |
| 5 | - | Nut, M8 x 1.25 mm A2K | 1 | |
| 6 | - | Screw, M8 x 30 mm 8.8 A2K | 2 | |
| 7 | 594648001 | Screw, M8 x 25 mm 8.8 A2K | 2 | |
| 8 | 594650201 | Lock spring | 2 | |
| 9 | 594647801 | Washer | 2 | |

**Spare parts list** Standard handle for Honda and Hatz, old version



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594144001 | Handle | 1 | |
| 2 | 594144101 | Handle | 1 | |
| 3 | 594144201 | Handle | 1 | |
| 4 | 594482801 | Link | 2 | |
| 5 | 594484501 | Cover | 2 | |
| 6 | 594485201 | Spacer sleeve | 2 | |
| 7 | 594485301 | Washer | 2 | |
| 8 | - | Screw, M6 x 40 mm A2K | 6 | |
| 9 | - | Lock nut, M8 -8 DIN 985 | 4 | |
| 10 | - | Disc spring, 18 x 8.2 x 1 mm, 0.71 x 0.32 x 0.04 in. | 4 | |
| 11 | - | Screw, M12 x 50 mm 8.8 A3K | 2 | |
| 12 | 594480301 | Sleeve bearing | 2 | |
| 13 | 594480401 | Shock absorber | 2 | |
| 14 | - | Spirol pin, 5 x 25 mm, 0.20 x 0.98 in. | 2 | |

**Spare parts list** Standard handle for Honda, new version




| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 595058101 | Screw, M12 x 50 mm 8.8 A3K , See section "Handle, standard". | 2 | |
| 2 | 594654701 | Sleeve | 2 | |
| 3 | 594480401 | Shock absorber | 2 | |
| 4 | 594654001 | Handle | 1 | |
| 5 | 594654101 | Handle | 1 | A |
| 6 | 594654401 | Bracket | 2 | |
| 7 | 594654201 | Sleeve | 2 | |
| 8 | 594654301 | Knob | 2 | |
| 9 | 595067101 | Washer, 5,3x10x1 300HV | 2 | |
| 10 | 594265501 | Retainer ring, 4.8 x 7 x 0.6 mm, 0.18 x 0.26 x 0.02 in. | 2 | |

Comments for Page: Standard handle for Honda, new version

(L)OCAL REMARKS

A | Upper

**Spare parts list** Vibration damped handle



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594526601 | Washer, 6.4x18x1.6 mm A2T | 16 | |
| 2 | 594482201 | Bracket | 2 | |
| 3 | 594480501 | Shock absorber | 2 | |
| 4 | 594482101 | Bracket | 2 | |
| 5 | 594525001 | Screw, M5 x 10 mm A2K | 8 | |
| 6 | 594524701 | Jointing nut, M6 x 30 mm 8.8 | 8 | |
| 7 | 594526701 | Screw, M6 x 12 mm 10.9 A2T | 16 | |
| 8 | 594480601 | Handle | 1 | A |
| 9 | 594166301 | Handle | 1 | B |


Comments for Page: Vibration damped handle

(L)OCAL REMARKS

A | Old version

B | New version, use together with new standard handles.

**Spare parts list** Labels



| Item | Part No. | Name | Qty | L |
|---|---|---|---|---|
| 1 | 594486201 | Label, start instruction | 1 | |
| 2 | 595376501 | Product label | 2 | |
| 5 | 594486301 | Instruction label | 1 | |
| 6 | 594515501 | Label, sound power level | 1 | |
| 7 | - | Drive screw | 4 | |
| 8 | - | Data plate (Not available separately) | 1 | |
| 9 | 595120501 | Product label | 1 | |
| 10 | 595051201 | Label lifting point | 1 | |
| 11 | 594535301 | Safety label, read instruction manual | 1 | |
| 12 | 594337101 | Label, use ear protectors | 1 | |
| 13 | 595065701 | Safety label, rotating V-belts | 1 | |

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Atlas Copco