ZENOAH®

PARTS LIST

DUSTERS

MD6210

NOTE :

1. Use HUSQVARNA ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. HUSQVARNA ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specitied in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

APPLICABLE SERIAL NUMBERS:

200101 and up

September 2019

Fig.1 ENGINE GROUP 01




Fig. 1 MD6210 ENGINE GROUP 01

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	2751-12111	CYLINDER	1	
2	2750-12130	BOLT M5x22	4	
3	2750-12210	GASKET	1	
4	2751-13160	INSULATER	1	
5	2751-13120	GASKET	1	
6	0263-90545	SCREW M5x45	2	
7	2750-12510	CYLINDER COVER	1	
8	2750-12520	BOLT M5x10	2	
9	2304-14001	DECOMP, ASSY	1	
10	1980-14610	WASHER	1	
11	2751-14511	COVER	1	
12	848L3015A1	MUFFLER ASSY	1	
13	2750-15210	GASKET	1	
14	2750-15160	BOLT M6x70	2	
15	2750-15170	BOLT M6x12	1	
16	848H302112	CRANKCASE COMP.	1	
17	2750-21140	GASKET	1	
18	84889F4200	BEARING	2	
19	T4019-21210	OIL SEAL	1	
20	8488AF4200	OIL SEAL	1	
21	01252-30530	BOLT M5x30	4	
22	04065-04218	SNAP RING	2	
23	2750-21211	COVER	1	
24	1565-72211	BOLT M4x16	1	
25	2750-21510	BOLT M6x40	6	
26	2750-41110	PISTON	1	
27	3366-41210	RING	2	
28	3366-41310	PIN	1	
29	3350-41320	SNAP RING	2	
30	1400-41410	BEARING	1	
31	2616-41510	WASHER	2	
32	848H304202	CRANKSHAFT COMP.	1	
33	1300-42410	SHIM	1	
34	1400-43230	NUT	2	
35	1000-43240	KEY	1	
36	2750-71111	ROTOR	1	
37	2750-71200	COIL ASSY	1	
38	2750-72150	BOLT	2	
39	1900-72112	PLUG CAP	1	
40	1900-72120	SPRING	1	
41	5500-72130	GROMMET	1	
42	2750-73200	CORD COMP.	1	
43	3699-90332	SPARK PLUG (NGK)	1	
44	2751-71220	CAP	1	
45	1487-75211	PULLEY	1	

Fig.2 ENGINE GROUP 02




Fig. 2 MD6210 ENGINE GROUP 02

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	2751-13130	GASKET	1	
2	8488K40010	CLAMP	1	
3	3405-16121	SCREW M4x14	1	
4	T4030-75100	RECOIL ASSY	1	
5	1180-75221	• SPRING	1	
6	T4030-75120	• REEL	1	
7	T4030-75140	• DOG	1	
8	1861-75150	• WASHER	1	
9	848G1K75E0	• SCREW	1	
10	1487-75160	• RETAINER	1	
11	1487-75170	• WASHER	1	
12	1400-75160	• ROPE	1	
13	1400-75170	• KNOB	1	
14	3460-75510	BOLT M5x20	4	
15	2751-86210	SUPPORT	1	
16	2751-81000	CARBURETOR ASSY	1	
17	2751-83101	CABLE COMP.	1	
18	595 84 14-03	TUBE	1	
19	2751-82110	BODY	1	
20	2751-82120	COVER	1	
21	1491-82311	ELEMENT	1	
22	1491-82352	SCREEN	1	
23	0263-90650	SCREW M6x50	2	
24	2751-82410	GASKET	1	
25	2751-82130	SCREW M4x14	3	
26	848L9F8504	TANK ASSY	1	
27	848L238510	• CAP ASSY	1	
28	4500-85300	•• HOLDER ASSY	1	
29	4500-85220	•• PACKING	1	
30	5601-85260	•• FILTER	1	
31	848L2385N0	•• STOPPER	1	
32	2751-85300	• PIPE COMP.	1	
33	5500-85310	•• GROMMET	1	
34	2751-85320	•• JOINT	1	
35	595 84 14-20	•• PIPE	1	
36	3302-85400	• FILTER ASSY	1	
37	1260-85460	• CLIP	1	
38	8488F50820	• TUBE	1	
39	1410-86130	• CLIP	1	
40	2751-85710	• SPRING	1	
41	1410-86130	CLIP	1	
42	3490-23612	SCREW M5x12	2	
43	1000-05095	TUBE	1	
44	1950-86120	CLIP	1	
45	2751-85410	CASE	1	
46	2751-85420	ELEMENT	1	
47	2751-31150	SCREW M5x25	1	
48	2754-75611	LABEL RECOIL	1	

Fig.3 CARBURETOR




Fig. 3 MD6210 CARBURETOR

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
	2751-81000	CARBURETOR ASSY	1	K15PG-5A
1	2751-81120	• BODY TOP	1	
2	2751-81030	• ADJUSTER, cable	1	
3	2751-81260	• LOCK NUT	1	
4	2751-81140	• GASKET, body top	1	
5	2751-81060	• SPRING, throttle	1	
6	2751-81070	• RECEIVE throttle spring	1	
7	2751-81230	• JET NEEDLE	1	#A175-3/5
8	1101-81190	• CLIP, needle	1	
9	2751-81150	• VALVE THROTTLE	1	
10	2751-81210	• NEEDLE JET	1	ø2.08
11	2751-81240	• MAIN JET	1	#80
12	2751-81650	• WIRE, DRAIN	1	
13	1420-81730	• PACKING, pump	1	
14	2174-81810	• DIAPHRAGM, pump	1	
15	2174-81820	• COVER, pump	1	
16	2751-81310	• CHAMBER	1	
17	2751-81320	• PACKING, chamber	1	
18	0263-10412	• SCREW M4x12	2	
19	0260-10310	• SCREW M3x10	4	
20	0263-10430	• SCREW M4x30	2	
21	2751-81890	• SPRING	2	
22	2174-81830	• PUMP, priming	1	
23	2751-81840	• PLATE, cap	1	
24	2174-81850	• SCREW M4	2	
25	3422-81130	• CAP	1	
26	2751-81250	• SCREW, slow stop	1	
27	1030-81000-31	• SPRING	1	

Fig.4 BLOWER GROUP




Fig. 4 MD6210 BLOWER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	2751-31111	VOLUTE CASE	1	
2	2751-31211	VOLUTE COVER	1	
3	2751-31150	SCREW M5x25	11	
4	3063-12223	GURD NET	1	
5	3468-25320	SCREW M5x16	3	
6	2751-31410	ELBOW	1	
7	07000-02095	O-RING	1	
8	2751-31420	SCREW M5x70	2	
9	3468-11180	NUT	2	
10	2750-31290	TUBE	1	
11	2750-31510	FAN	1	
12	3407-12210	BOLT M5x40	4	
13	2750-31612	ENGINE COVER	1	
14	2750-31150	SCREW M5x25	4	
15	2750-32102	FRAME COMP.	1	
16	3490-21121	• RING	2	
17	3460-21311	PAD	1	
18	3495-21321	CLIP	4	
19	2751-32300	BAND ASSY	2	
20	2751-32310	• BAND (A)	1	
21	848L5036B1	• BAND (B)	1	
22	2751-32510	DAMPER	2	
23	2751-32610	DAMPER	2	
24	2751-32620	NUT	4	
25	3460-11830	LABEL, caution	1	
26	2750-72230	CLAMP	1	
27	848L9337G0	STOPPER	2	

Fig.5 SPRAY GROUP




Fig. 5 MD6210 SPRAY GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	2751-35101	TANK ASSY	1	
2	3460-31204	• CAP ASSY	1	
3	3460-31223	•• GASKET	1	
4	2751-33410	PLATE	1	
5	2751-33420	COLLAR	2	
6	2751-33430	SCREW TP5x60	2	
7	2751-33101	CASE ASSY	1	
8	2751-33201	• SHUTTER ASSY	1	
9	2751-33220	•• COVER	1	
10	2751-33230	•• ARM	1	
11	3460-13340	•• PIN	1	
12	3422-61150	•• SNAP RING	1	
13	2751-33260	• PIN	1	
14	07000-11004	• O-RING	2	
15	2751-33311	• SHAFT	1	
16	07000-12010	• O-RING	1	
17	3460-13430	• SNAP RING	1	
18	07000-11007	• O-RING	1	
19	2751-33120	• GASKET	1	
20	2751-35511	CLAMP	2	
21	2751-35520	PIN	2	
22	2751-35530	SCREW TP5x35	4	
23	2751-31701	HOOK ASSY	2	
24	2751-31710	• HOOK	1	
25	2751-31720	• LEVER	1	
26	2751-31731	• BRACKET	1	
27	2751-35520	PIN	2	
28	2751-33502	GUIDE PIPE	1	
29	2751-33530	GASKET	1	
30	2751-34111	INDICATOR	1	
31	2751-34120	BRACKET	1	
32	3468-25320	SCREW TP5x16	3	
33	3495-25110	LEVER, throttle	1	
34	3468-11180	NUT	2	
35	01642-20508	WASHER	1	
36	2751-34210	SCREW	1	
37	2751-34220	HOLDER	1	
38	2751-34230	PLATE	1	
39	2751-34240	SPRING	1	
40	3495-25510	SWITCH	1	
41	1601-72411	CAP	1	
42	3495-25810	TUBE	1	
43	2751-35530	SCREW TP5x35	4	
44	2751-34311	LEVER	1	
45	2751-34350	PLATE	1	

Fig.5 SPRAY GROUP




Fig. 5 MD6210 SPRAY GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
46	3468-25320	SCREW TP5x16	4	
47	2751-34410	KNOB	1	
48	2751-34511	ROD	1	
49	3063-21721	BALL JOINT	1	
50	0280-70504	NUT	1	
51	2751-34520	SPRING	1	
52	2751-34530	PLATE	1	
53	2751-34540	SCREW M5x10	1	
54	2751-35811	LABEL, brand	1	
55	2751-35820	LABEL, caution	1	
56	3460-11840	LABEL, warning	1	

Fig.6 SPRAY EQUIPMENT, TOOLS




Fig. 6 MD6210 SPRAY EQUIPMENT, TOOLS

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	3490-51110	HOSE, flexible	1	
2	2751-51510	CLAMP	1	
3	2751-51520	CLAMP	1	
4	3495-51202	SWIVEL JOINT	1	
5	3495-51321	PIPE, extension	2	
6	3495-51331	PIPE	1	
7	3073-91211	CHAIN	1	
8	3073-91410	MASK	1	
9	2751-91000	TOOL SET	1	
10	3073-91111	• PLUG WRENCH	1	
11	3540-91120	• SPANNER	1	
12	3020-61110	OUTLET, flat	1	
13	3495-51400	GRIP ASS'Y	1	
14	3495-51410	• GRIP	1	
15	3495-51420	• WING BOLT	1	
16	3495-51430	• WING NUT	1	
17	3238-15230	• WASHER	2	