

# Service Bulletin B4190005A-06

Action required	Χ
Information only	

# SB, schedule and time get lost and display is flashing 2019-06

#### Affected models

Model	Model Art.no.	PNC	Serial R	lange	
			Start	End	
	15001-20	967646803			
	15001-22	967646804		n/a	
	15001-28	967646810			
	15001-24	967646805			
	15001-35	967646808			
SILENO city / 250m <sup>2</sup>	15001-26	967646806			
	15001-36	967646809	1844**** r		
	15001-32	967646807			
	150	15001-33	967646811		
	15001-34	967646812			
	15001-37	967646813			
	15001-38	967646814			
	15001-41	967646815			

#### **Affected markets**

DE/AT, CH, UK, NO/SE, FI/EE/LV/LT, BE/NL/FR, DK, PL/CZ/SK/HU/RU/UA, BG/ROHR/GR/SL/RU, IT/ES/PT, KR, AUS/NZ, CA

## **Description**

The error is caused by a defective HMI board.

The customer notes that the mower does not mow at the correct time, or may not mow at all. The customer finds that the system time has shifted by several hours. When opening the hatch, the display keeps turning on and off without any action.

Affected are Sileno City mower 250m<sup>2</sup>(Art.no: 15001-\*).

English Page 1 of 2



# Service Bulletin B4190005A-06

Action required	Χ
Information only	

#### **Action**

	Product sold to end user	Residual inventory not yet sold	
What is required:	d: Service is required Service is not required		
When to do:	Only if encountered		
What to do:	Replace Display board (HMI board), (spare parts are not affected)		
How to do:	like descripted in workshop manual chapter 6.7.4		

#### **Parts information**

New part no.	Part description	Quantity	Old part no.
592 91 00-01	PCBA HMI BOARD	1	same

## Warranty reporting information

Normal warranty rules apply. A warranty claim must be filed for each unit serviced, even if service is labour only. Please include full serial number. All claims must be sent through our warranty process using only the information listed below:

Field	Selection or Entry
Claim type (inventory)	-
Claim type (end users)	1 - Warranty
Failure description	Refer to SB number
Component code	754 Display
Defect code	08 Cracked / Split / Broken / Fractured
Labour allowance	4

## **Additional information**

Please send the defect HMI boards to:

Dynamic Precision AB Att: Repair Center Östergårdsgatan 19 SE-524 23 Herrljunga Sweden

#### **Revision History**

Re	v.	Date	Order id.	Description
A	١	28.06.2019		Created
E	3	01.07.2019		Updated Additional information

English Page 2 of 2