


REPAIR PARTS MANUAL MODEL NO. XT625N21RH3 MFG. ID. NO. 96132005200 Rotary Lawn Mower

For Parts and Service, contact our authorized distributor: call 1-800-849-1297 For Technical Assistance: call 1-800-829-5886



432678 01.19.10 BY

Printed in U.S.A.



ROTARY LAWN MOWER - - MODEL NUMBER XT625N21RH3 (MFG. ID. NUMBER 96132005200)

ROTARY LAWN MOWER - - MODEL NUMBER XT625N21RH3 (MFG. ID. NUMBER 96132005200)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	194177X428	Control Bar	29	407500X005	Wheel Adjusting Bracket,	52	413906	Kit, Housing (Includes #46)
2	194179X479	Upper Handle			Front, RH	53	851084	Screw, Hex Head, Grade 8
3	169708X479	Lower Handle	30	401629	Spacer			3/8-24 x 1-3/8
4	194788	Rope Guide	31	165760	Discharge Deflector	54	850263	Helical Lockwasher
5	132004	Nut, Hex	32	401624X004	Selector Spring, Rear	55	851074	Hardened Washer
6	191574	Handle Bolt	33	87877	Selector Knob	56	406712	21" Blade
7	66426	Wire Tie	34	401176X004	Axle Arm Assembly,	57	420097	Blade Adapter
8	74780512	Bolt, Hex Head			Rear, LH	58	152124	Hinge Spring
		5/16-18 x 3/4	35	426589	Locknut, Hex 5/16-18	59		Engine, Briggs & Stratton,
9	154132	Hinge Bracket	36	401638	Shoulder Bolt 5/16-18			Model Number 122T02-
10	165754	Mulcher Door	37	193931X428	Wheel & Tire Assembly,			1207-EA (For engine
11	176556	Engine Zone Control Cable			Front 7 x 1-3/4			service and replacement
12	750634	Hex Washer Head Screw	39	409149	Nut, Hex			parts, call Briggs & Stratton
ω		#10-24 x 1/2	40	411949	Frame, Grassbag			at 1-800-233-3723)
13	429930X004	Up-Stop Bracket	41	88652	Screw, Hinge	61	409148	Flanged Locknut
14	189713X428	Handle Knob	42	405421	Spring, LH	62	73800400	Nut, Hex
15	51793	Hairpin Cotter	43	405423	Spring, RH	65	88348	Washer, Flat
18	17600406	Screw	44	184193	Bolt, Rear Door	66	197480	O-Ring
19	401174X004	Axle Arm Assembly,	45	150406	Hex Head Thread Rolling	67	197991	Clip, Cable
		Front, LH			Screw 3/8-16 x 1	73	401630	Washer, Curved, Cylindrical
20	401175X004	Axle Arm Assembly,	46	404763	Danger Decal	74	851201X004	Washer, Special, Engine
		Front, RH	47	751153	Nut, Hex	75	413693	Kit, Rear Baffle
21	418655	Kit, Rear Skirt	48	401177X004	Axle Arm Assembly,			(Includes 3 Screws)
22	401621X004	Selector Spring, Front			Rear, RH	76	410589	Baffle, Rear
23	401814X428	Rear Door Assembly	49	193926X428	Wheel & Tire Assembly,	77	17411312	Screw, Rear Baffle
25	410385X479	Handle Bracket, LH			Rear 12 x 1-3/4		404764	Warning Decal (not shown)
26	410386X479	Handle Bracket, RH	50	412336	Grassbag			
28	407499X005	Wheel Adjusting Bracket, Front, LH	51	147286	Hinge Rod			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.



LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of two (2) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine, transaxle/transmission components, battery (except as noted below) or components parts thereof. Please refer to the applicable manufacturer's warranty on these items.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by the manufacturer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 45 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In the event you have a claim under this Warranty, you must return the product to an authorized service dealer.

Should you have any unanswered questions concerning this Warranty, contact:

Poulan Pro Customer Service Department 1030 Stevens Creek Road Augusta, GA 30907 USA In Canada contact: Poulan Pro Customer Service Department 5855 Terry Fox Way Mississauga, Ontario L5V 3E4

giving the model number, serial number and date of purchase of your product and the name and address of the authorized dealer from whom it was purchased. THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN FOR OUR EXPRESSED WARRANTIES. Some areas do not allow the limitation of consequential damages or limitations of how long an implied Warranty may last, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may have other rights which vary from locale to locale.

This is a limited Warranty within the meaning of that term as defined in the Magnuson-Moss Act of 1975.